

USER GUIDE how to install the seatpost adapter



Start with careful cleaning of the seatpost – remove primarily the grease. If it's an aluminium seatpost, use a bit of carbon paste – spread it into the inner clamp of the adapter.



Put the adapter on the seatpost – the highest point of the inner clamp must be directed the same way as the seat is. Tighten the screws, until it goes. Alternately – tighten a bit one, then the second one and so on. Don't use electric screw driver, please.



Put the seatpost back to the frame of your bike. The adapter should be ideally down by the frame. Control if the screws are tighten enough – don't try to tighten them too much, just as it goes by hand.



Take the drag bar and connect it to the adapter. Take the long screw and tighten it. Then connect the trailer to the bar. Just to be sure, control the seatpost again, if it's good tightened in the frame.



MAINTAINANCE : clean the adapter from time to time, especially after riding in the mud. For cleaning use either compressed air or water. Try to clear mud and little stones primarily from the bearings. You can also lubricate the adapter, but beware to spray any oil in the inner clamp. If so, then dry it, otherwise you risk that the adapter will creep on the seatpost.